



# fantastik® Multi-Surface Disinfectant Degreaser

## CLEANS, DISINFECTS, DEGREASES & DEODORIZES

- Kills 99.99% of bacteria & viruses when used as directed on hard non-porous surfaces
- Removes 100% tough soap scum and grease
- Leaves a fresh scent
- Multi-purpose daily cleaner



































#### **USE OVERVIEW**

#### FOR USE IN:

- Businesses
- Offices
- Restaurants
- Retail Stores
- Hotels & Motels
- Bed and Breakfast Inns
- Homes

- Convenience Stores
- Automotive Shops
- Buses
- Cars
- Cruise Ships
- Airplanes

Cleans, disinfects and deodorizes kitchen and bath hard non-porous surfaces. Kills bacteria, viruses, mould & mildew, and fungi.

Cleans appliances, refrigerator exteriors, dishwasher exteriors, countertops, cooktops, stovetops, oven exteriors, bathroom fixtures, sinks, showers, toilets, floors, and siding. Use on stainless steel, chrome, aluminum, bronze, brushed nickel, sealed granite, sealed marble, quartz, acrylic, fiberglass, and tile. Spot test all other surfaces in an inconspicuous area. Unplug electrical appliances before using.

#### TO CLEAN:

Spray 6-8 inches (15-20cm) from surface until thoroughly covered. For tough jobs, let stand several minutes before wiping. No need to rinse. Prevents mould and mildew.

#### TO DISINFECT:

Allow surface to remain wet for 10 minutes and wipe. Pre-clean heavily soiled areas. Avoid contact with food. For surfaces and or objects that may come in to direct contact with food, a rinse with potable water is recommended.

#### STORAGE AND DISPOSAL

#### STORAGE:

Store in a cool, dry place, in original container out of reach of children and pets.

#### **DISPOSAL:**

Never place unused product down any indoor or outdoor drain. For information on disposal of unused, unwanted product, contact the manufacturer or the appropriate municipal/provincial/territorial agency or product stewardship organization.

#### **CONTAINER HANDLING:**

Refillable Container. Refill this container with fantastik® Multi-Surface Disinfectant Degreaser only. Do not reuse this container for any other purpose.

#### PRECAUTIONARY STATEMENTS

## KEEP OUT OF REACH OF CHILDREN AND PETS.

Do not apply this product around electrical equipment due to the possibility of shock hazard.

FOR COMMERCIAL AND INSTITUTIONAL USE ONLY.

# ORDERING INFORMATION

## **Description**

fantastik\* Multi-Surface Disinfectant Degreaser Trigger, 946ml, Case Qty 8 fantastik\* Multi-Surface Disinfectant Degreaser Refill, 3.78L, Case Qty 4

#### Case UPC

100-6291300078-9 100-6291300079-6

#### **SCJ Code**

311837 311929

### **AVAILABLE FROM:**



Trademark owned by/IMPORTED BY, S. C. JOHNSON AND SON, LIMITED, BRANTFORD, ON, CANADA N3T 5R1. FOR SALE IN CANADA ONLY. ©2020

Questions? Comments? Call 1-800-558-5566

A family company since 1886.



For additional information on use, ingredients, precautions and disposal please visit: www.scjohnson-professional.com

